

PerKit™ Antibody DM1 Conjugation Kit (CM11410.01x1 and CM11410.01x3) User Reference Guide

Contents

Important Notes & Contact Information	2
Kit Components.....	3
Safety Information	3
Labeling Chemistry.....	3
Support	4
Protocol.....	5
1. Lab Instrumentation Needed	5
2. Prepare Site and Reagents for Labeling Experiment	5
3. Preparation of Antibody Samples for Conjugation	6
4. SMCC Labeling (Step 1 in Scheme 1).....	7
5. Purification to Remove Excess SMCC.....	8
6. DM1 Labeling (Step 2 in Scheme 1)	9
7. Purification of Conjugate	9
Other Considerations	11
1. Concentration Determination for IgG Antibody (Unlabeled)	11
2. Concentration Determination for ADC	11
3. MW Calculation.....	12
4. Drug-to-Antibody Ratio (DAR) and Characterization by UV and HPLC	12
5. Characterization of ADC by HIC HPLC	12
6. Characterization of ADC by SEC HPLC	13
7. ADC Stabilizing Buffer	13
8. Recommended Storage Conditions	13
9. Submit Samples for HPLC Analysis.....	13
Appendix: Typical Kit Performance Data (LC analysis, CellMosaic)	15

Important Notes & Contact Information

READ BEFORE USING ANY RESOURCES PROVIDED HEREIN

The information provided in this document and the methods included in this package are for information purposes only. CellMosaic provides no warranty of performance or suitability for the purpose described herein. The performance of this kit in labeling may be affected by many different variables, including but not limited to the purity and complexity of the starting materials, differences in preparation techniques, operator ability, and environmental conditions.

Sample data are provided for illustration and example purposes only and represent a small dataset used to verify kit performance in the CellMosaic laboratory. Information about the chemicals and reagents used in the kit are provided as necessary.

For Research Use Only. Not for Use in Diagnostic Procedures.

The information in this document is subject to change without notice. CellMosaic assumes no responsibility for any errors that may appear in this document. In no event shall CellMosaic be liable, whether in contract, tort, warranty, or under any statute or on any other basis for special, incidental, indirect, punitive, multiple, or consequential damages in connection with or arising from this document, including but not limited to the use of this product thereof.


NOTICE TO PURCHASER: LIMITED LICENSE

The purchase of this product includes a limited, non-transferable license to use this product to practice the labeling methods using the reagents solely for the purchaser's research activities. The license granted herein is personal to the original purchaser and may not be transferred to any other party outside the purchaser's company. No other right or license is conveyed or granted either expressly, by implication or by estoppel, to resell or repackage this product. Further information can be obtained by contacting:

Director of Licensing
c/o CellMosaic, Inc.
10-A Roessler Road, Woburn, MA 01801.
Phone: 781-463-0002
Fax: 781-998-4694
E-mail: info@cellmosaic.com

Kit Components

This kit provides materials to conjugate mertansine (DM1) with SMCC (succinimidyl trans-4-(maleimidylmethyl)cyclohexane-1-carboxylate) linker onto one (CM11410.01x1) or three (CM11410.01x3) antibody samples. Scale of each reaction: 0.1 mg (protein content). This kit is optimized for IgG (MW: ~150KDa). If you have other antibody type, please contact CellMosaic for any suggestion.

 Upon receipt, please remove **Box 1** and store in a freezer at or below -20°C.
Store **Box 2** in a refrigerator at 2-8°C.

	Name	Part #	Quantity (CM11410.01x1)	Quantity (CM11410.01x3)	Storage condition
Box 1	DM1 (red label)	CM11002.01	1 unit	3 units	-20°C
	SMCC (green label)	CM12104.1	1 unit	3 units	
Box 2	Solution A (blue label)	CM01008	0.5 mL	0.5 mL	2-8°C
	Buffer A (orange label)	CM02001	4 mL	12 mL	
	Buffer B (indigo label)	CM02005	4 mL	12 mL	
	Storage Buffer (1 x PBS buffer) (grey label)	CM02013	5 mL	20 mL	
	ADC Stabilizing PBS Buffer (5x) (pink label)	CM02022	0.5 mL	1.5 mL	
	Centrifugal Filter Devices	CM03CD050A	3	9	
	Collection Tubes for Filter	CM03CT0	6	18	
	Desalting Spin Column	CM03SG50	2	6	
	Collection Tubes for Spin Column	CM03CT9	2	6	
	0.5 mL Eppendorf Tubes	CM03CT7	2	6	
	1.5 mL Centrifuge Tube	CM03CT2	2	6	
	Hazardous Waste Bag(s)	CM03HZ1	1	3	
User Material	IgG Antibody	N/A	NOT PROVIDED (User Supplied Material, 0.1 mg IgG needed per reaction)		

Safety Information


Warning: some of the chemicals used can be potentially hazardous and can cause injury or illness. Please read and understand the Safety Data Sheets (SDS) available at CellMosaic.com before you store, handle, or use any of the materials.

Labeling Chemistry


The kit is designed to label any antibody (IgG type) with mertansine (DM1) using SMCC linker. The user supplies the antibody. This kit includes SMCC and DM1, which can be coupled to the antibody sequentially via surface amines (a method developed by Immunogen). The product is then purified to remove any unreacted drug.

Key features of this conjugation kit:

- Offers a simple and easy way to label IgG with DM1 with minimum exposure to the toxin
- Stable linkage
- Fast and easy preparation: 6 h preparation and <2 h hands-on time
- All reagents and supplies included for preparation and purification
- Average 2-4 DM1 labeling per antibody
- Less than 5% of antibody aggregation and >99% of conjugated products by SEC (size-exclusion chromatography)



Drug Information:



- **Name:** Mertansine (DM1)
- **CAS number:** 139504-50-0
- **Chemical Formula:** C₃₅H₄₈ClN₃O₁₀S
- **MW:** 738.29
- **Mechanism of action:** Inhibits cell division by blocking the polymerization of tubulin


Requirement for antibody (IgG):

1. Preferably > 90% pure by gel electrophoresis
2. Total amount: 0.1 mg (protein content)

Support

Customer can request a recommendation for the conjugation if the molecule has a special feature or a low amount of antibody. CellMosaic also provides additional support services to customers who need help analyzing the final conjugates by HPLC.

Protocol



Scheme 1. Schematic diagram of the work flow for preparing antibody-DM1 conjugates

1. Lab Instrumentation Needed

- Vortex mixer, centrifuge (preferably refrigerated, 14,000 g capable), mini-centrifuge
- Pipettes and tips
- Timer
- Incubator or shaker set at 25 °C or RT
- Chemical hood
- Support stand, lab frame, or any support rod for desalting column
- Flask
- Personal protection equipment (lab coat, safety glasses, and chemical resistant nitrile gloves)

2. Prepare Site and Reagents for Labeling Experiment

Note: DM1 and SMCC are very hydrophobic. Antibody-drug conjugates with DM1 via SMCC linker tend to aggregate and precipitate out from the solution over time. It is recommended that the labeling experiment be planned only a few days before your other experiments. If not possible, then please use the provided stabilization PBS buffer to store under recommended conditions.

Ensure you have use personal protection equipment (lab coat, safety glasses, and chemical resistant nitrile gloves) while handling DM1. Locate a clean space inside a chemical hood.

- A1.** Remove **Box 1** containing **DM1** (red label) and **SMCC** (green label) from the -20°C freezer and warm to RT before opening the bag.
- A2.** Remove **Box 2** from the refrigerator. Take the hazardous waste bag and place it inside the chemical hood for solid waste disposal. Bring the rest of the items to a lab bench.
- A3.** Briefly spin the centrifuge tube containing **DM1**. Place the **DM1** tube in a tube holder inside a chemical hood and wait until the antibody is ready for conjugation.
- A4.** Set the temperature of the incubator or shaker to 25 °C.

3. Preparation of Antibody Samples for Conjugation

Items needed: Filter Devices (CM03CD050A), Collection Tubes for Filter (CM03CT0), Buffer A (CM02001, Orange label), 0.5 mL Eppendorf Tube (CM03CT7), Clean Centrifuge Tubes (not provided in the kit).

Total amount of antibody used for the conjugation is 0.1 mg (protein content measured by UV) per reaction.

B1. Insert the **Filter Device** into one of the provided collection tube (microcentrifuge tube with the cap attached). Perform the step based on the following conditions.

- ✓ If your antibody is supplied as a lyophilized solid, dissolve the antibody in 500 µL of **deionized water** and then transfer the entire contents to the **Filter Device**.
- ✓ If your antibody is supplied in < 500 µL buffer, transfer your antibody sample to the **Filter Device** directly. Add **Buffer A** to make up the total volume to 500 µL and cap it.
- ✓ If the volume of your antibody sample is between 500 and 1000 µL, divide the volume into two **Centrifugal Filter Devices** and add the antibody sample to the filter device. Add **Buffer A** to make up the total volume to 500 µL in each device and cap them.
- ✓ If the volume of your antibody sample is >1000 µL, add up to 500 µL of sample to the two **Filter Devices** and cap them. Repeat Step **B1-B4** until all of the antibody sample goes into the **Filter Device**. Move on to Step **B5**. Add **Buffer A** to make up the total volume to 500 µL in each device for the last refill.

B2. Place the capped **Filter Device** into the centrifuge rotor, aligning the cap strap toward the center of the rotor; counterbalance with a similar device.

B3. Spin the **Filter Device** at 14,000 x g for 6 minutes (preferably cooled to 4°C) to concentrate to < **100 µL** (Spin time depends on many factors. The typical spin time for a 500 µL sample is approximately 5 to 10 minutes. The typical volume is ~40 µL after spinning for 6 minutes on an Eppendorf 5417R at 4°C.)

B4. Remove the assembled device from the centrifuge and separate the **Filter Device** from the collection tube. Transfer the filtrate from the collection tube to a clean centrifuge tube (not provided). **Save the filtrate until the experiments are done.**

B5. Insert the **Filter Device** back to the collection tube. Add 400-450 µL of **Buffer A** to make up the total volume to 500 µL. Then place the capped **Filter Device** into the centrifuge rotor,

aligning the cap strap toward the center of the rotor; counterbalance with a similar device. Spin the device at 14,000 x g to concentrate to < **100 µL**. Remove the assembled device from the centrifuge and separate the **Filter Device** from the collection tube. Transfer the filtrate from the collection tube to a clean centrifuge tube (not provided). **Save the filtrate until the experiments are done.**

B6. Repeat **Step B5** two more times. For the last repeat, spin the **Filter Device** at 14,000 x g to concentrate to < **20 µL**.

Note: If you divide your samples into two **Centrifugal Filter Devices**, you can combine the samples into one **Centrifugal Filter Device** during the last repeat of **Step B6**.

B7. Transfer the concentrated sample from the **Filter Device** to a 0.5 mL Eppendorf tube (Use the pipetman to estimate the approximate volume of the concentrated sample. Calculate the volume of **Buffer A** needed for rinsing the **Filter Device** in **Step B8**. The total volume of the sample should be ~**47.7 µL** after combining the concentrated sample from **Step B7** and the rinsing solution from **Step B8**.)

B8. Add 10-20 µL of **Buffer A** to the **Filter Device** to rinse. Stir it gently with a pipet tip, then transfer the entire contents to the 0.5 mL Eppendorf tube from **Step B7**.

B9. Vortex the combined antibody sample for 30 seconds and then centrifuge to ensure no liquid is in the cap.

4. SMCC Labeling (Step 1 in Scheme 1)

Items needed: **SMCC** (CM12104.1, green label), **Solution A** (CM01008, blue label), **Antibody Solution** from **Step B9**.

C1. Spin the centrifuge tubes containing **SMCC** (green label) before opening it.

C2. Spin **Solution A** (blue label) to ensure there is no liquid in the cap before opening it. Add 10 µL of **Solution A** to the **SMCC** tube from **Step C1**. Vortex for 30 seconds to 1 minute to dissolve the reagent and then centrifuge to ensure no liquid is in the cap (**Solution A** will be also used in **Step E2**).

Tip for solubility check: Check the bottom of the micro-centrifuge tube to see if the solution is clear of any solid residue.

C3. Transfer **2.3 µL** of **SMCC solution** from **Step C2** to the antibody solution from **Step B9**.

C4. Vortex the solution for 30 seconds, and then centrifuge to ensure no liquid is in the cap. Mix at 25 °C or RT for 2 h.

Tip for mixing: You can use a nutator, a shaker, vortex, or an incubator shaker for mixing. If you are using end to end nutating, make sure your centrifuge is capped properly. If you don't have

any of this equipment, you can let the centrifuge tube sit at the bench with manual mixing by pipetting every 20 minutes.

5. Purification to Remove Excess SMCC

Items needed: Filter Device (CM03CD050A), Collection Tubes for Filter (CM03CT0), Buffer B (CM02005, indigo label), 0.5 mL Eppendorf Tube (CM03CT7), Clean Centrifuge Tubes (not provided in the kit), Antibody Solution from **Step C4**.

D1. Insert the **Filter Device** into one of the provided collection tubes (microcentrifuge tube with the cap attached). Transfer the SMCC labeled antibody solution from **Step C4** into the **Filter Device** directly. Wash the centrifuge tube once with 450 μ L **Buffer B**, transfer the solution to the **Filter Device** (total volume 500 μ L), and cap it. Place the capped **Filter Device** into the centrifuge rotor, aligning the cap strap toward the center of the rotor; counterbalance with a similar device.

D2. Spin the **Filter Device** at 14,000 x g for 6 minutes (preferably cooled to 4°C) to concentrate to < 100 μ L.

D3. Remove the assembled device from the centrifuge and separate the **Filter Device** from the collection tube. Transfer the filtrate from the collection tube to a clean centrifuge tube (not provided). **Save the filtrate until the experiments are done.**

D4. Add 400-450 μ L of **Buffer B** to make up the total volume to 500 μ L. Then place the capped **Filter Device** into the centrifuge rotor, aligning the cap strap toward the center of the rotor; counterbalance with a similar device. Spin the device at 14,000 x g to concentrate to < 100 μ L. Remove the assembled device from the centrifuge and separate the **Filter Device** from the collection tube. Transfer the filtrate from the collection tube to a clean centrifuge tube (not provided). **Save the filtrate until the experiments are done.**

D5. Repeat **Step D4** two more times. For the last repeat, spin the **Filter Device** at 14,000 x g to concentrate to < 20 μ L.

D6. Transfer the concentrated sample from the **Filter Device** to a 0.5 mL Eppendorf tube (Use the pipetman to estimate the approximate volume of the concentrated sample. Calculate the volume of **Buffer B** needed for rinsing the **Filter Device** in **Step D7**. The total volume of the sample should be ~44 μ L after combining the concentrated sample from **Step D6** and the rinsing solution from **Step D7**.)

D7. Add 10-20 μ L of **Buffer B** to the **Filter Device** to rinse. Stir it gently with a pipet tip, then transfer the entire contents to the 0.5 mL Eppendorf tube from **Step D6**.

D8. Vortex the combined antibody sample for 30 seconds and then centrifuge to ensure no liquid is in the cap.

6. DM1 Labeling (Step 2 in Scheme 1)

Items needed: DM1 (CM11002.01, red label), Solution A (CM01008, blue label), Hazardous Waste Bag, Antibody Solution from **step D8**.

E1. With personal protection equipment on, carefully open the centrifuge tube of DM1 from **Step A3**.

E2. Add **10 μL** of **Solution A** to the **DM1** tube. Vortex for 30 seconds to 1 minute to dissolve the reagent and then centrifuge to ensure no liquid is in the cap.

E3. Transfer **6 μL** of **DM1 solution** from **Step E2** to the centrifuge tube containing antibody from **Step D8**. When you add the DM1 solution, place the pipette tip inside the antibody solution and then dispense the DM1 slowly with stirring using the pipette tip. **Dispose of the pipette tip and DM1 tube in the solid waste bag.**

E4. Cap the centrifuge tube. Mix at 25 °C or RT for 1 h.

Tip for time saving: While waiting for the reaction to complete, you can move on to **Step F1** and equilibrate the column for purification.

7. Purification of Conjugate

Items needed: Desalting Spin Column (CM03SG50), Storage Buffer (1x PBS) (CM02013, grey label), Collection Tubes for Spin Column (CM03CT9), 1.5 mL Centrifuge Tube (CM03CT2), Hazardous Waste Bag (CM03HZ1), DM1–Antibody Solution from **Step E4**.

F1. Take out 2 desalting spin columns, remove the bottom red cap. Spin for 1 min at 750 x g before opening the top cap.

F2. Apply 400 μL of PBS buffer (grey label) to the top-center of the resin of each column. Let it remain at RT for 15 min to swell the resin.

F3. Spin for 1 min at 750 x g and discard the flow through.



F4. Repeat **Steps F2–F3** once. Spin immediately after applying PBS without wait and discard the flow through.

F5. Insert the spin columns into clean 1.5 mL collection tubes.

F6. Spin the DM1–antibody solution from **Step E4** to ensure there is no liquid in the cap before opening it. Add 1xPBS buffer to make up the total volume of the DM1 solution to 60 μL .

F7. Slowly apply up to 30 μL of each conjugate solution from **Step E4** to the top-center of the resin of each spin column without disturbing the resin bed (2 x 30 μL).

F8. Washing the tube with 40 μL of PBS buffer, then apply 20 μL of PBS buffer to the top-center of the resin of each spin column to make up the volume to 50 μL in




each spin column. **Dispose of the centrifuge tube in the solid waste bag.**



The resin may detach a little from the column to form a pillar with an unbalanced resin bed due to the centrifuge force. Make sure the sample and subsequent PBS buffer is applied slowly in the resin and not run down the sides of the resin bed. Wait for the conjugate solution to enter the resin before applying PBS buffer. Avoid touching the resin bed with the pipette tip.

F9. Rotate/align the spin column so that the higher resin bed side is against the wall of the centrifuge rotor and the lower resin bed faces the center of the centrifuge (same centrifuge force). Spin for 2 min at 750 x g to collect the fractions.



F10. Transfer and combine the fractions from the two collection tubes into the provided 1.5 mL centrifuge tube and cap it. **Dispose of the Desalting Spin Columns, Collection Tubes in the solid waste bag and seal the bag. Dispose of the waste following regulations appropriate for your area.**

F11. Determine the concentration and the estimated DAR by UV/Vis spectrophotometry (see other considerations).

F12. If the ADC is not used immediately for the experiment, add **Stabilization PBS buffer (5x)** (Total volume of ADC x 0.25) (pink label) to the ADC from **Step F10**. Aliquot and store the conjugate in a < -20°C freezer or lyophilize to dryness for long-term storage.

Conjugate is Ready for Your Experiment

- **Specification for your product:** DM1-labeled antibodies with an average drug-to-antibody ratio (DAR) of 2-4. A typical batch contains over 99% conjugated products by SEC is free of any unreacted drug. The approximate concentration of the ADC is 0.5 mg/mL in PBS buffer assuming 50% recovery. You can determine the concentration and the estimated DAR of the ADC by UV/Vis spectrophotometer (see other considerations).

Other Considerations

1. Concentration Determination for IgG Antibody (Unlabeled)

The accuracy of the IgG amount is important for obtaining an optimized DAR in this protocol. The simplest assay method for determining IgG concentration in solution is to measure the absorbance of the IgG at 280 nm (UV range) ($A_{1\text{ mg/mL}} = 1.4$).

If your antibody comes with a buffer that has no UV absorbance at 280 nm, you can measure the UV absorbance prior to starting an experiment.

$$\text{Concentration (mg/mL) of IgG} = \frac{(A_{280})}{1.4}$$

If your antibody comes with a buffer that has UV absorbance at 280 nm, you can determine the concentration in **step B11** after exchanging it with Buffer A and assuming **95%** recovery of the IgG after buffer exchange. Buffer A does not contain any substances that will interfere with the UV measurement at 280 nm. The total volume of Buffer A added in **Step B10** can be estimated based on the initially estimated amount of antibody and will not affect the conjugation too much if the volume is off to some extent.

$$\text{Concentration (mg/mL) of Starting IgG} = \frac{(A_{280})}{1.4 \times 0.95}$$

After calculating the total amount, follow the calculations in **Steps B10, C3, D10, E3, F5, and F6** to obtain the correct volumes to be added in each step.

2. Concentration Determination for ADC

To determine the concentration, dilute your conjugate from **Step E7** with 1x PBS buffer. Measure the UV absorbance of the conjugate at 280 nm (A_{280}) using a UV spectrometer and calculate the concentration based on the following formula:

$$\text{Concentration } (\mu\text{M}) \text{ of the dilute sample} = \frac{(A_{280}) * 1000000}{L (210000 + n * 5700)}$$

$$\text{Concentration (mg/mL) of the dilute sample} = \frac{(A_{280}) \times 150000}{L (210000 + n * 5700)}$$

Where **L** is the UV cell path length (cm). If you are using a 1 cm UV cell, you can dilute the conjugate 4 times to obtain a good reading.

Where **n** is the average molar ratio of DM1 per antibody. Use 4.0 if you do not have the experimental value of your conjugates.

For a typical IgG with MW of 150,000, the molar extinction coefficient is $210,000 \text{ M}^{-1}\text{cm}^{-1}$. The molar extinction coefficient for DM1 is $5700 \text{ M}^{-1}\text{cm}^{-1}$ (Ravi V.J. Chari *et. al.* Immunoconjugates

containing novel maytansinoids: promising anticancer drugs. *Cancer research* **1992**, 52, 127-131.)

3. MW Calculation

Calculation of the MW of the conjugate:

$$\text{MW(ADC)} = n \times 957 + 150000$$

Where **n** is the average molar ratio of DM1 per antibody. Use **3.0** if you do not have the experimental value of your conjugates.

4. Drug-to-Antibody Ratio (DAR) and Characterization by UV and HPLC

In this kit, the target DAR is 2-4.

To estimate the DAR, you can obtain the UV absorbance ratio (R) of your conjugate at 252 nm and 280 nm.

$$R = \frac{(A_{252})}{(A_{280})}$$

The unlabeled antibody will have an R value of 0.4 – 0.5. A DM1-ADC with DAR of 2 – 4 will have an R value of 0.65 – 0.86.

You can also use the following formula to calculate the estimated DAR (for reference only):

$$\text{DAR} = \frac{(21 \times R - 8.74)}{(2.8 - 0.57 \times R)}$$

DM1: $E_{280 \text{ nm}} = 5700 \text{ M}^{-1}\text{cm}^{-1}$ and $E_{252 \text{ nm}} = 28044 \text{ M}^{-1}\text{cm}^{-1}$

Antibody: $E_{280 \text{ nm}} = 210000 \text{ M}^{-1}\text{cm}^{-1}$ and $E_{252 \text{ nm}} = 87360 \text{ M}^{-1}\text{cm}^{-1}$

(Extinction coefficient values of DM1 and antibody at 252 nm were taken from this reference: Ravi V.J. Chari *et. al.* Immunoconjugates containing novel maytansinoids: promising anticancer drugs. *Cancer research* **1992**, 52, 127–131.)

5. Characterization of ADC by HIC HPLC

For ADCs prepared via surface amines of the antibody, hydrophobic interaction chromatography (HIC) HPLC can be used to check if an antibody is labeled or not. However, due to the highly heterogeneous nature of surface amine labeling, antibody loaded with the same number of drugs (same DAR) may have slightly different hydrophobicity. For a typical DM1 ADC, a broad peak will be seen without clear separation of the peaks.

CellMosaic offers an HIC buffer set ([Product #: CM02025](#)) for our customers to use with any HIC column. The CM02025 product sheet contains all of the information and methodology needed to run an HIC HPLC analysis.

If you do not have access to an HPLC facility, you can send your sample to CellMosaic for analysis.

6. Characterization of ADC by SEC HPLC

DM1 is very hydrophobic. This kit is designed to minimize the aggregation and precipitation issues generally seen with DM1 labeling. However, you may still notice some solid precipitate out or ADC aggregation during the reaction. The precipitate will be removed during purification. Depending on the properties of your antibody, recovery will be 30-60%. If you are concerned with the aggregation, you can use size exclusion chromatography (SEC) to check the extent of aggregation. SEC separates the conjugates by apparent molecular weight (MW) or size in aqueous solution. The larger the MW of the conjugate, the earlier it elutes. By comparing the SEC profile of unlabeled IgG and the ADC, you can estimate how much aggregation is in the ADC.

CellMosaic offers two SEC standards ([Product #: CM92004](#) and [CM92005](#)) for our customers to use with any SEC column. The CM92004 product sheet contains all of the information and methodology you need to run an SEC HPLC analysis.

If you do not have access to an HPLC facility, you can send your sample to CellMosaic for analysis.

7. ADC Stabilizing Buffer

CellMosaic's proprietary ADC stabilizing PBS buffer (5x) ([Product #: CM02022](#)) contains 5x PBS buffer and other stabilizers to prevent the hydrophobic drugs from interacting with each other during storage, which would cause the ADCs to precipitate out. Stabilization buffer also helps preserve the structure of the ADCs during lyophilization. The buffer is biocompatible and can be used directly for any *in vitro* and *in vivo* studies. For more information on the stabilization buffers, please check our website.

8. Recommended Storage Conditions

ADC with DM1 is relatively stable. Based on our preliminary data, the conjugate made with this kit can remain stable in PBS buffer for several weeks at 2-8°C. Do not freeze DM1 ADC.

The stability of your conjugate may be different due to your antibody and should be checked by either HPLC or UV. If you need to store the ADCs for a longer period of time, dilute your ADC in Stabilization PBS buffer (5x) (included in this kit). Aliquot and store the conjugate in a < -20°C freezer or lyophilize to dryness. Avoid repeated freeze and thaw cycles.

9. Submit Samples for HPLC Analysis

If you are submitting samples to CellMosaic for SEC and HIC analysis, please follow these instructions:

- 1) Go online: <https://www.cellmosaic.com/hplc-analysis/>, select SEC HPLC Analysis ([Product# AS0023](#)) and HIC HPLC Analysis ([Product#: AS0025](#)), choose the quantity (number of samples. Bulk discounts available for multiple samples) and submit the order. Alternatively, you can email info@cellmosaic.com for a quote and to place the order.


- 2) Dilute your un-conjugated antibody in PBS buffer to 1 mg/mL, and then transfer 50 μ L of the diluted solution to a 500 μ L micro-centrifuge tube. Label the vial properly.
- 3) Transfer 50 μ L of ADC (non-diluted solution) to a 500 μ L micro-centrifuge tube and label the vial properly.
- 4) Ship your samples with a cold pack for overnight delivery.

Appendix: Typical Kit Performance Data (LC analysis, CellMosaic)

Antibody information: A therapeutic antibody (human IgG1 subtype)

Kit Lot number: 5513.S9.053018

Figure 1: SEC HPLC analysis of antibody (blue color) and purified ADC-DM1 (red color) (Inset: UV/Vis spectra of the unlabeled antibody and ADC-DM1.) Scale of the reaction: 1 mg (CM11410.1)



Summary of the result:

Test Reactions	1 mg Scale Reaction (CM11410.1)	0.1 mg Scale Reaction (CM11410.01)
R value (only consider the 10.46 min peak product)	0.78	0.72
Average DAR based on R value	3.24	2.7
Maleimide groups per antibody after SMCC labeling	3.8	3.2
Extend of antibody aggregation (%)	3.8	3.16
Unreacted antibody (%)	0	0
Unreacted DM1 (%)	0	0
Recovery (%)	38	46

R value (A252 nm/A280 nm) of unlabeled antibody: 0.515

The higher the average DAR of ADC-DM1, the greater the percentage of the antibody aggregates and the lower the overall recovery.