

PerKit™ Antibody DM1 Conjugation Kit (CM11410x1 and CM11410x3) User Reference Guide

Contents

Important Notes & Contact Information	2
Kit Components.....	3
Safety Information	3
Labeling Chemistry.....	3
Support	4
Protocol.....	5
1. Lab Instrumentation Needed.....	5
2. Prepare Site and Reagents for Labeling Experiment	5
3. Preparation of Antibody Samples for Conjugation	6
4. SMCC Labeling (Step 1 in Scheme 1).....	7
5. Purification to Remove Excess SMCC.....	8
6. DM1 Labeling (Step 2 in Scheme 1)	9
7. Purification of Conjugate	10
Other Considerations.....	11
1. Concentration Determination for IgG Antibody (Unlabeled)	11
2. Concentration Determination for ADC	11
3. MW Calculation.....	12
4. Drug-to-Antibody Ratio (DAR) and Characterization by UV and HPLC.....	12
5. Characterization of ADC by HIC HPLC	12
6. Characterization of ADC by SEC HPLC.....	13
7. ADC Stabilizing Buffer	13
8. Recommended Storage Conditions	13
9. Submit Samples for HPLC Analysis.....	13
Appendix: Typical Kit Performance Data (LC analysis, CellMosaic)	15



CellMosaic, Inc.
10A Roessler Road
Woburn, MA 01801
USA

Phone: 781-463-0002
Fax: 781-998-4694
Email: info@cellmosaic.com
Website: www.cellmosaic.com

Important Notes & Contact Information

READ BEFORE USING ANY RESOURCES PROVIDED HEREIN

The information provided in this document and the methods included in this package are for information purposes only. CellMosaic provides no warranty of performance or suitability for the purpose described herein. The performance of this kit in labeling may be affected by many different variables, including but not limited to the purity and complexity of the starting materials, differences in preparation techniques, operator ability, and environmental conditions.

Sample data are provided for illustration and example purposes only and represent a small dataset used to verify kit performance in the CellMosaic laboratory. Information about the chemicals and reagents used in the kit are provided as necessary.

For Research Use Only. Not for Use in Diagnostic Procedures.

The information in this document is subject to change without notice. CellMosaic assumes no responsibility for any errors that may appear in this document. In no event shall CellMosaic be liable, whether in contract, tort, warranty, or under any statute or on any other basis for special, incidental, indirect, punitive, multiple, or consequential damages in connection with or arising from this document, including but not limited to the use thereof.


NOTICE TO PURCHASER: LIMITED LICENSE

The purchase of this product includes a limited, non-transferable license to use this product to practice the labeling methods using the reagents solely for the purchaser's research activities. The license granted herein is personal to the original purchaser and may not be transferred to any other party outside the purchaser's company. No other right or license is conveyed or granted either expressly, by implication or by estoppel, to resell or repackage this product. Further information can be obtained by contacting:

Director of Licensing
c/o CellMosaic, Inc.
10-A Roessler Road, Woburn, MA 01801.
Phone: 781-463-0002
Fax: 781-998-4694
E-mail: info@cellmosaic.com

Kit Components

This kit provides materials to conjugate 1 to 3 mg of one (CM11410x1) or three (CM11410x3) antibody samples (**IgG**) with mertansine (DM1) using SMCC (succinimidyl trans-4-(maleimidylmethyl)cyclohexane-1-carboxylate) linker.

 Upon receipt, please remove **Box 1** and store in a freezer at or below -20°C. Store **Box 2** in a refrigerator at 2-8°C.

	Name	Part #	Quantity (CM11410x1)	Quantity (CM11410x3)	Storage condition
Box 1	DM1 (red label)	CM11002	1 unit	3 units	-20°C
	SMCC (green label)	CM12104	1 unit	3 units	
Box 2	Solution A (blue label)	CM01008	0.5 mL	1.5 mL	2-8°C
	Buffer A (orange label)	CM02001	4 mL	12 mL	
	Buffer B (indigo label)	CM02005	4 mL	12 mL	
	Storage Buffer (1 x PBS buffer) (grey label)	CM02013	20 mL	60 mL	
	ADC Stabilizing PBS Buffer (5x) (pink label)	CM02022	0.5 mL	1.5 mL	
	Centrifugal Filter Device	CM03CD050A	3	9	
	Desalting Column	CM03SG10	1	3	
	Collection Tubes	CM03CT0	6	18	
	1.5 mL Centrifuge Tube	CM03CT2	3	9	
	Hazardous Waste Bag	CM03HZ1	1	3	
User Material	IgG Antibody	N/A	NOT PROVIDED (User Supplied Material, 1-3 mg IgG needed per reaction)		

Reaction Scale: The protocol is optimized for conjugating 3 mg of IgG antibody. If you have less than 3 mg of IgG, use the calculations in **Steps B10, C3, D10, E3, F5, and F6** to obtain the correct volumes to be added in each step.

Safety Information

Warning: some of the chemicals used can be potentially hazardous and can cause injury or illness. Please read and understand the Safety Data Sheets (SDS) available at CellMosaic.com before you store, handle, or use any of the materials.


Labeling Chemistry

The kit is designed to label any antibody (IgG type) with mertansine (DM1) using SMCC linker. The user supplies the antibody. This kit includes SMCC and DM1, which can be coupled to the antibody


sequentially via surface amines (a method developed by Immunogen). The product is then purified to remove any unreacted drug.

Key features of this conjugation kit:

- Offers a simple and easy way to label IgG with DM1 with minimum exposure to the toxin
- Stable linkage
- Fast and easy preparation: 6 h preparation and <2 h hands-on time
- All reagents and supplies included for preparation and purification
- Average 2-4 DM1 labeling per antibody
- Less than 5% of antibody aggregation and >99% of conjugated products by SEC (size-exclusion chromatography)



Drug Information:



- **Name:** Mertansine (DM1)
- **CAS number:** 139504-50-0
- **Chemical Formula:** C₃₅H₄₈ClN₃O₁₀S
- **MW:** 738.29
- **Mechanism of action:** Inhibits cell division by blocking the polymerization of tubulin


Requirement for antibody (IgG):

1. Preferably > 90% pure by gel electrophoresis
2. Total amount: 1-3 mg protein content as measured by UV. Note: the accuracy of your protein amount is the single most important factor to obtaining an optimized DAR. Please refer to the section Other Considerations in this manual to measure the protein amount.

Support

Customer can request a recommendation for the conjugation if the IgG has a special feature or a less than 1 mg of IgG to be labeled. CellMosaic provides other accessory tools, such as buffers, standards, and reagents for ADC research. CellMosaic also provides fee-based support services to customers who need help analyzing the final conjugates by HPLC.

Protocol



Scheme 1. Schematic diagram of the workflow for preparing antibody-DM1 conjugates starting with 3 mg of IgG (volume of reagents varies if the amount of IgG is < 3 mg).

1. Lab Instrumentation Needed

- Vortex mixer, centrifuge (preferably refrigerated, 14,000 g capable), mini-centrifuge
- Pipettes and tips
- Timer
- Incubator or shaker set at 25 °C or RT
- Chemical hood
- Support stand, lab frame, or any support rod for desalting column
- Flask
- Personal protection equipment (lab coat, safety glasses, and chemical resistant nitrile gloves)

2. Prepare Site and Reagents for Labeling Experiment

Note: DM1 and SMCC are very hydrophobic. Antibody-drug conjugates with DM1 via SMCC linker tend to aggregate and precipitate out from the solution over time. It is recommended that the labeling experiment be planned for only a few days before your other experiments. If not possible, then please use the stabilization PBS buffer to store under recommended conditions.

Ensure you use personal protection equipment (lab coat, safety glasses, and chemical resistant nitrile gloves) while handling DM1. Locate a clean space inside a chemical hood.

- A1.** Remove **Box 1** containing **DM1** (red label), **Solution A** (blue label), and **SMCC** (green label) from the -20°C freezer and warm to RT before opening the bag.
- A2.** Remove **Box 2** from the refrigerator. Take the hazardous waste bag and place it inside the chemical hood for solid waste disposal. Bring the rest of the items to a lab bench.
- A3.** Briefly spin the centrifuge tube containing **DM1**. Place the **DM1** tube in a tube holder inside a chemical hood and wait until the antibody is ready for conjugation.

Tip for opening centrifuge tubes after mixing: Always spin the tubes to ensure no liquid is in the cap.

- A4.** Set the temperature of the incubator or shaker to 25 °C.

3. Preparation of Antibody Samples for Conjugation

Items needed: Filter Devices (CM03CD050A), Collection Tubes (CM03CT0), Buffer A (CM02001, orange label), 1.5 mL Centrifuge Tube (CM03CT2), Clean Centrifuge Tubes (not provided in the kit).

Total amount of antibody used for the conjugation is 3 mg (protein content measured by UV) per reaction.

Reaction Scale: If you have less than 3 mg of antibody, use the calculations in **Steps B10, C3, D9, E2, F5, and F6** to obtain the correct volumes to be added in each step.

B1. Insert the **Filter Device** into one of the provided collection tubes (microcentrifuge tube with the cap attached). Perform the step based on the following conditions.

- ✓ If your antibody is supplied as a lyophilized solid, dissolve the antibody in 500 µL of **deionized water** and then transfer the entire contents to the **Filter Device**.
- ✓ If your antibody is supplied in < 500 µL buffer, transfer your antibody sample to the **Filter Device** directly. Add **Buffer A** to make up the total volume to 500 µL and cap it.
- ✓ If the volume of your antibody sample is between 500 and 1000 µL, divide the volume into two **Centrifugal Filter Devices** and add the antibody sample to the filter device. Add **Buffer A** to make up the total volume to 500 µL in each device and cap them.
- ✓ If the volume of your antibody sample is >1000 µL, add up to 500 µL of sample to the two **Filter Devices** and cap them. Repeat **Steps B1-B4** until all of the antibody sample is transferred into the **Filter Device**. Move on to **Step B5**. Add **Buffer A** to make up the total volume to 500 µL in each device for the last refill.

B2. Place the capped **Filter Device** into the centrifuge rotor, aligning the cap strap toward the center of the rotor; counterbalance with a similar device.

B3. Spin the **Filter Device** at 14,000 x g for 8 minutes (preferably cooled to 4°C) to concentrate to < **100 µL** (Spin time depends on many factors. The typical spin time for a 500 µL sample is

approximately 8 to 20 minutes. The typical volume is ~40 µL after spinning for 8 minutes on an Eppendorf 5417R at 4°C).

B4. Remove the assembled device from the centrifuge and separate the **Filter Device** from the collection tube. Transfer the filtrate from the collection tube to a clean centrifuge tube (not provided). **Save the filtrate until the experiments are done.**

B5. Insert the **Filter Device** back into the collection tube. Add 400-450 µL of **Buffer A** to make up the total volume to 500 µL. Next, place the capped **Filter Device** into the centrifuge rotor, aligning the cap strap toward the center of the rotor; counterbalance with a similar device. Spin the device at 14,000 x g to concentrate to < **100 µL**. Remove the assembled device from the centrifuge and separate the **Filter Device** from the collection tube. Transfer the filtrate from the collection tube to a clean centrifuge tube (not provided). **Save the filtrate until the experiments are done.**

B6. Repeat **Step B5** two more times.

B7. Transfer the concentrated sample from the **Filter Device** to a 1.5 mL micro-centrifuge tube (use the pipetman to estimate the approximate volume of the concentrated sample).

B8. Add 40 to 100 µL of **Buffer A** to the **Filter Device** to rinse (actual volume of **Buffer A** added will depend upon the calculated total volume in **Step B10**). Stir it gently with a pipet tip, then transfer the entire contents to the 1.5 mL micro-centrifuge tube from **Step B7**.

B9. Repeat **Step B8** once.

B10. Add **Buffer A** to the 1.5 mL micro-centrifuge tube from **Step B9** to make up the total volume of the sample to **570 ± 5 µL** and cap it.

Calculation 1 for Less Antibody (Ab):

$$\text{Total volume of the antibody in Step B10 } (\mu\text{L}) = \text{Ab in mg} \times 190$$

B11. Vortex the combined antibody sample for 30 seconds and then centrifuge to ensure no liquid is in the cap.

4. SMCC Labeling (Step 1 in Scheme 1)

Items needed: SMCC (CM12104, green label), Solution A (CM01008, blue label), Antibody Solution from **Step B11**.

C1. Spin the centrifuge tube containing **SMCC** (green label) before opening it.

C2. Spin **Solution A** (blue label) before opening it. Add **30 µL** of **Solution A** to the **SMCC** tube from **Step C1**. Vortex for 30 seconds to 1 minute to dissolve the reagent and then spin the centrifuge tube before opening it (**Solution A** will be also used in **Step E2**).

Tip for solubility check: Check the bottom of the micro-centrifuge tube to see if the solution is clear of any solid residue.

C3. Transfer the entire **SMCC solution** from **Step C2** to the antibody solution from **Step B11**.

Calculation 2 for Less Antibody (Ab):

$$\text{Volume of SMCC solution to be transferred in Step C3 } (\mu\text{L}) = \text{Ab in mg} \times 10$$

C4. Vortex the solution for 30 seconds, and then centrifuge to ensure no liquid is in the cap. Mix at 25 °C or RT for 2 h.

Tip for mixing: You can use a nutator, a shaker, vortex, or an incubator shaker for mixing. If you are using end to end nutating, make sure your centrifuge is capped properly. If you don't have any of this equipment, you can let the centrifuge tube sit at the bench with manual mixing by pipetting every 20 minutes.

5. Purification to Remove Excess SMCC

Items needed: Filter Device (CM03CD050A), Collection Tubes, 1.5 mL Centrifuge Tube (CM03CT2), Buffer B (CM02005, indigo label), Clean Centrifuge Tubes (not provided in the kit), Antibody Solution from **Step C4**.

D1. Insert the **Filter Device** into one of the provided collection tubes (microcentrifuge tube with the cap attached). Transfer the entire SMCC labeled antibody solution from **Step C4** into the **Filter Device** directly. Add **Buffer B** to make up the total volume to 500 μL if the total volume of antibody solution is less than 500 μL . Place the capped **Filter Device** into the centrifuge rotor, aligning the cap strap toward the center of the rotor; counterbalance with a similar device.

D2. Spin the **Filter Device** at 14,000 x g for 8 minutes (preferably cooled to 4°C) to concentrate to < 100 μL .

D3. Remove the assembled device from the centrifuge and separate the **Filter Device** from the collection tube. Transfer the filtrate from the collection tube to a clean centrifuge tube (not provided). **Save the filtrate until the experiments are done.**

D4. Insert the **Filter Device** back to the collection tube. If there is any leftover SMCC labeled antibody solution from **Step C4**, transfer the rest of the solution directly into the **Filter Device**. Otherwise, go directly to **Step D5**. Add **Buffer B** to make up the total volume to 500 μL . Spin the device at 14,000 x g to concentrate to < 100 μL . Transfer the filtrate from the collection tube to a clean centrifuge tube (not provided). **Save the filtrate until the experiments are done.**

D5. Insert the **Filter Device** back to the collection tube. Add 400-450 μL of **Buffer B** to make up the total volume to 500 μL . Spin the device at 14,000 x g to concentrate to < 100 μL . Transfer the filtrate from the collection tube to a clean centrifuge tube (not provided). **Save the filtrate until the experiments are done.**

D6. Repeat **Step D5** two more times.

D7. Transfer the concentrated sample from the **Filter Device** to a 1.5 mL micro-centrifuge tube (use the pipetman to measure the approximate volume of the concentrated sample).

D8. Add 30 to 100 μL of **Buffer B** to the **Filter Device** to rinse (actual volume of **Buffer B** added will depend upon the calculated total volume in **Step D10**). Stir it gently with a pipet tip, then transfer the entire contents to the 1.5 mL micro-centrifuge tube from **Step D7**.

D9. Repeat **Step D8** once.

D10. Add **Buffer B** to make up the total volume of the sample to **510 \pm 5 μL** and cap it.

Calculation 3 for Less Antibody (Ab):

$$\text{Total Volume of SMCC Labeled Antibody in Step D10 } (\mu\text{L}) = \text{Ab in mg} \times 170$$

D11. Vortex the combined antibody sample for 30 seconds and then spin down.

Note: The average maleimide groups per antibody is 4. If necessary, you can purchase the maleimide assay kit ([Product#: CM90002](#)) separately from CellMosaic to assay the maleimide content. The kit is simple and easy to use. Mix 7 μL of the antibody solution from **Step D11** with 63 μL of **Buffer A** (included in the maleimide assay kit) for the assay following the protocol provided with the maleimide assay kit. Final concentration of the antibody is 39.2 μM if the total volume of the antibody is 510 μL .

6. DM1 Labeling (Step 2 in Scheme 1)

Items needed: **DM1 (CM11002, red label)**, **Solution A (CM01008, blue label)**, **Hazardous Waste Bag (CM03HZ1)**, **Antibody Solution from Step D11**.

E1. With personal protection equipment on, carefully open the centrifuge tube of **DM1** from **Step A3**.

E2. Add **90 μL** of **Solution A** to the **DM1** tube. Vortex for 30 seconds to 1 minute to dissolve the reagent and then centrifuge to ensure no liquid is in the cap.

E3. Transfer the entire **DM1 solution** from **Step E2** to the centrifuge tube containing antibody from **Step D11**. When you add the **DM1** solution, place the pipette tip inside the antibody solution and then dispense the **DM1** slowly while swirling the pipette tip. **Dispose of the pipette tip and DM1 tube in the solid waste bag.**

Calculation 4 for Less Antibody (Ab):

$$\text{Volume of DM1 Solution to be Transferred in Step E3 } (\mu\text{L}) = \text{Ab in mg} \times 30$$

Dispose of the remainder of the DM1 solution in the hazardous waste bag.

E4. Cap the centrifuge tube. Mix at 25°C or RT for 1 h.

Time saving tip: While waiting for the reaction to complete, you can move on to **Step F1** and equilibrate the column for purification.

7. Purification of Conjugate

Items needed: Desalting Column (CM03SG10), Storage Buffer (1x PBS, CM02013, grey label), ADC Stabilizing PBS Buffer (5x) (CM02022, pink label), 1.5 mL Centrifuge Tube (CM03CT2), Hazardous Waste Bag (CM03HZ1), Antibody Solution from **Step E4**.

F1. In a chemical hood, securely attach the **Desalting Column** to a support stand, lab frame, or any support rod. Remove the top and bottom caps from the column and allow the excess liquid to flow through by gravity. Collect the liquid in a flask.

F2. Add 5 mL of **Storage Buffer** and allow the buffer to completely enter the gel bed by gravity flow.

F3. Repeat **Step F2** twice times.

F4. Spin the DM1 labeled antibody solution from **Step E4** before opening it. Add the entire antibody solution to the column. Allow the sample to enter the gel bed completely. **Dispose of the centrifuge tube in the solid waste bag.**

F5. Add 400 μ L of **Storage Buffer** and allow the liquid to enter the gel bed completely (**Note:** this elution buffer does not contain any of your product, you can let it drain to the waste).

Calculation 5 for Less Antibody (Ab):

$$\text{Volume of Storage buffer in Step F5 } (\mu\text{L}) = 1000 - \text{Ab in mg} \times 200$$

F6. Place a 1.5 mL centrifuge tube under the column. Add 1.1 mL of **Storage Buffer** to the column. Collect the eluent by gravity and allow the buffer to enter the gel bed completely.

Calculation 6 for Less Antibody (Ab):

$$\text{Volume of Storage buffer in Step F6 } (\mu\text{L}) = 500 + \text{Ab in mg} \times 200$$

F7. Label the tube as your product. Store your conjugate at 4°C. **Dispose of the Desalting Column in the solid waste bag and seal the bag. Dispose of the waste following regulations appropriate for your area.**

F8. Determine the concentration and the estimated DAR by UV/Vis spectrophotometry (see other considerations).

F9. If the ADC is not used immediately for the experiment, add **Stabilization PBS buffer (5x)** (pink label) to the ADC from **Step F7**. Aliquot and store the conjugate in a < -20°C freezer or lyophilize to dryness for long-term storage.

Conjugate is Ready for Your Experiment

- **Specification for your product:** DM1-labeled antibodies with an average drug-to-antibody ratio (DAR) of 2-4. A typical batch contains more than 99% conjugated products by size exclusion chromatography (SEC) and is free of any unreacted drug. The approximate concentration of the ADC is 1.23 mg/mL in PBS buffer assuming 45% recovery. You can determine the concentration and estimated DAR of the ADC by UV/Vis spectrophotometer (see Other Considerations).

Other Considerations

1. Concentration Determination for IgG Antibody (Unlabeled)

The accuracy of the IgG amount is important for obtaining an optimized DAR in this protocol. The simplest assay method for determining IgG concentration in solution is to measure the absorbance of the IgG at 280 nm (UV range) ($A_{1\text{ mg/mL}} = 1.4$).

If your antibody comes with a buffer that has no UV absorbance at 280 nm, you can measure the UV absorbance prior to starting an experiment.

$$\text{Concentration (mg/mL) of IgG} = \frac{(A_{280})}{1.4}$$

If your antibody comes with a buffer that has UV absorbance at 280 nm, you can determine the concentration in **step B11** after exchanging it with Buffer A and assuming **95%** recovery of the IgG after buffer exchange. Buffer A does not contain any substances that will interfere with the UV measurement at 280 nm. The total volume of Buffer A added in **Step B10** can be estimated based on the initially estimated amount of antibody and will not affect the conjugation too much if the volume is off to some extent.

$$\text{Concentration (mg/mL) of Starting IgG} = \frac{(A_{280})}{1.4 \times 0.95}$$

After calculating the total amount, follow the calculations in **Steps B10, C3, D10, E3, F5, and F6** to obtain the correct volumes to be added in each step.

2. Concentration Determination for ADC

To determine the concentration of the ADC, dilute your conjugate from **Step E7** with 1x PBS buffer. Measure the UV absorbance of the conjugate at 280 nm (A_{280}) using a UV spectrometer and calculate the concentration based on the following formula:

$$\text{Concentration } (\mu\text{M}) \text{ of the dilute sample} = \frac{(A_{280}) * 1000000}{L (210000 + n * 5700)}$$

$$\text{Concentration (mg/mL) of the dilute sample} = \frac{(A_{280}) \times 150000}{L(210000 + n * 5700)}$$

Where **L** is the UV cell path length (cm). If you are using a 1 cm UV cell, you can dilute the conjugate 4 times to obtain a good reading.

Where **n** is the average molar ratio of DM1 per antibody. Use 4.0 if you do not have the experimental value of your conjugates.

For a typical IgG with MW of 150,000, the molar extinction coefficient is $210,000 \text{ M}^{-1}\text{cm}^{-1}$. The molar extinction coefficient for DM1 is $5700 \text{ M}^{-1}\text{cm}^{-1}$ (Ravi V.J. Chari *et. al.* Immunoconjugates

containing novel maytansinoids: promising anticancer drugs. *Cancer research* **1992**, *52*, 127-131.)

3. MW Calculation

Calculation of the MW of the conjugate:

$$\text{MW(ADC)} = n \times 957 + 150000$$

Where **n** is the average molar ratio of DM1 per antibody. Use **3.0** if you do not have the experimental value of your conjugates.

4. Drug-to-Antibody Ratio (DAR) and Characterization by UV and HPLC

In this kit, the target DAR is 2-4.

To estimate the DAR, you can obtain the UV absorbance ratio (R) of your conjugate at 252 nm and 280 nm.

$$R = \frac{(A_{252})}{(A_{280})}$$

The unlabeled antibody will have an R of 0.4 – 0.5. A DM1-ADC with DAR of 2 – 4 will have an R of 0.65 – 0.86.

You can also use the following formula to calculate the estimated DAR (for reference only):

$$\text{DAR} = \frac{(21 \times R - 8.74)}{(2.8 - 0.57 \times R)}$$

DM1: $E_{280 \text{ nm}} = 5700 \text{ M}^{-1}\text{cm}^{-1}$ and $E_{252 \text{ nm}} = 28044 \text{ M}^{-1}\text{cm}^{-1}$

Antibody: $E_{280 \text{ nm}} = 210000 \text{ M}^{-1}\text{cm}^{-1}$ and $E_{252 \text{ nm}} = 87360 \text{ M}^{-1}\text{cm}^{-1}$

(Extinction coefficient values of DM1 and antibody at 252 nm were taken from this reference: Ravi V.J. Chari *et. al.* Immunoconjugates containing novel maytansinoids: promising anticancer drugs. *Cancer research* **1992**, *52*, 127–131.)

5. Characterization of ADC by HIC HPLC

For ADCs prepared via surface amines of the antibody, hydrophobic interaction chromatography (HIC) HPLC can be used to check if an antibody is labeled or not. However, due to the highly heterogeneous nature of surface amine labeling, antibody loaded with the same number of drugs (same DAR) may have slightly different hydrophobicity. For a typical DM1 ADC, a broad peak will be seen without clear separation of the peaks.

CellMosaic offers an HIC buffer set ([Product #: CM02025](#)) for our customers to use with any HIC column. The CM02025 product sheet contains all of the information and methodology needed to run an HIC HPLC analysis.

If you do not have access to an HPLC facility, you can send your sample to CellMosaic for analysis.

6. Characterization of ADC by SEC HPLC

DM1 is very hydrophobic. This kit is designed to minimize the aggregation and precipitation issues generally seen with DM1 labeling. However, you may still notice some solid precipitate out or ADC aggregation during the reaction. The precipitate will be removed during purification. Depending on the properties of your antibody, recovery will be 30-60%. If you are concerned with the aggregation, you can use size exclusion chromatography (SEC) to check the extent of aggregation. SEC separates the conjugates by apparent molecular weight (MW) or size in aqueous solution. The larger the MW of the conjugate, the earlier it elutes. By comparing the SEC profile of unlabeled IgG and the ADC, you can estimate how much aggregation is in the ADC.

CellMosaic offers two SEC standards ([Product #: CM92004](#) and [CM92005](#)) for our customers to use with any SEC column. The CM92004 product sheet contains all of the information and methodology you need to run an SEC HPLC analysis.

If you do not have access to an HPLC facility, you can send your sample to CellMosaic for analysis.

7. ADC Stabilizing Buffer

CellMosaic's proprietary ADC stabilizing PBS buffer (5x) ([Product #: CM02022](#)) contains 5x PBS buffer and other stabilizers to prevent the hydrophobic drugs from interacting with each other during storage, which would cause the ADCs to precipitate out. Stabilization buffer also helps preserve the structure of the ADCs during lyophilization. The buffer is biocompatible and can be used directly for any *in vitro* and *in vivo* studies. For more information on the stabilization buffers, please check our website.

8. Recommended Storage Conditions

ADC with DM1 is relatively stable. Based on our preliminary data, the conjugate made with this kit can remain stable in PBS buffer for several weeks at 2-8°C. Do not freeze DM1 ADC.

The stability of your conjugate may be different due to your antibody and should be checked by either HPLC or UV. If you need to store the ADCs for a longer period of time, dilute your ADC in Stabilization PBS buffer (5x) (included in this kit). Aliquot and store the conjugate in a < -20°C freezer or lyophilize to dryness. Avoid repeated freeze and thaw cycles.

9. Submit Samples for HPLC Analysis

If you are submitting samples to CellMosaic for SEC and HIC analysis, please follow these instructions:

- 1) Go online: <https://www.cellmosaic.com/hplc-analysis/>, select SEC HPLC Analysis ([Product# AS0023](#)) and HIC HPLC Analysis ([Product#: AS0025](#)), choose the quantity (number of samples. Bulk discounts available for multiple samples) and submit the order. Alternatively, you can email info@cellmosaic.com for a quote and to place the order.


- 2) Dilute your un-conjugated antibody in PBS buffer to 1 mg/mL, and then transfer 50 μ L of the diluted solution to a 500 μ L micro-centrifuge tube. Label the vial properly.
- 3) Transfer 50 μ L of ADC (non-diluted solution) to a 500 μ L micro-centrifuge tube and label the vial properly.
- 4) Ship your samples with a cold pack for overnight delivery.

Appendix: Typical Kit Performance Data (LC analysis, CellMosaic)

Antibody information: A therapeutic antibody (human IgG1 subtype)

Kit Lot number: 5513.S9.053018

Figure 1: SEC HPLC analysis of antibody (blue color) and purified ADC-DM1 (red color) (Inset: UV/Vis spectra of the unlabeled antibody and ADC-DM1.) Scale of the reaction: 1 mg (CM11410.1)



Summary of the result:

Test Reactions	1 mg Scale Reaction (CM11410.1)	0.1 mg Scale Reaction (CM11410.01)
R value (only consider the 10.46 min peak product)	0.78	0.72
Average DAR based on R value	3.24	2.7
Maleimide groups per antibody after SMCC labeling	3.8	3.2
Extend of antibody aggregation (%)	3.8	3.16
Unreacted antibody (%)	0	0
Unreacted DM1 (%)	0	0
Recovery (%)	38	46

R value (A252 nm/A280 nm) of unlabeled antibody: 0.515

The higher the average DAR of ADC-DM1, the greater the percentage of the antibody aggregates and the lower the overall recovery.